

1

10mm

Install the threaded side of the spigot to the side outlet port (2) of the diverter mixer, apply lock seal and tighten using a 10mm Allen key (not supplied).

2

Push the adaptor onto the spigot so that it is firmly attached.

3

HOLD

2.5mm

Hold the adaptor in place, ensuring it sits level with the mixer, then install the grub screws firmly, **do not over tighten the grub screws.**